

COMMERCIAL GAS HIGH EFFICIENCY WATER HEATERS



300 Maddox Simpson Parkway
Lebanon, TN 37090

**FOR MODELS:
SBD71120(N,P) through SBD100390(N,P)E
Series 118 & 119**

**INSTALLATION CONSIDERATIONS - PRE SERVICE CHECKS -
CONSTRUCTION - OPERATION & SERVICE - TROUBLESHOOTING**



SERVICING SHOULD ONLY BE PERFORMED BY A QUALIFIED SERVICE TECHNICIAN

TABLE OF CONTENTS

INTRODUCTION	2
Qualifications.....	2
Service Warning	2
Service Reminder.....	2
Tools Recommended	2
INSTALLATION CONSIDERATIONS	3
Instruction Manual.....	3
Closed Water Systems.....	3
Thermal Expansion	3
Air Requirements	3
Contaminated Air.....	3
VENTING.....	4
Power Vent Kits For Sidewall Venting	5
GAS SUPPLY SYSTEMS	6
Supply Gas Regulator	6
Gas Piping.....	7
FEATURES AND COMPONENTS	9
The Hydrocannon (Self-Cleaning System).....	9
Automatic Flue Damper	9
GAS CONTROL VALVE	10
White Rodgers Integrated Temperature Control Switch.....	11
Status LEDS.....	11
Electronic Ignition Control/ Ignition Module.....	12
SEQUENCE OF OPERATION FLOW CHART.....	13
TROUBLESHOOTING CHECKLIST	14
GENERAL SERVICE CHART	15
FAULT AND WARNING CODES	16
Step 1. Troubleshooting The Water Heaters	16
Flue Damper	17
Effikal RVGP-KSF-Series Flue Damper Troubleshooting Guide..	18
Step 2: Test For 24Vac Between Black And Orange On Damper PC Board.....	19
Step 3: Test the Three AMP FUSE.....	19
Symptoms for a blown fuse.....	20
Symptoms for a working fuse.....	20
Step 4: Test For 24VAC Between Black And Yellow On Damper PC Board.....	21
Step 5: Wire Harness Test	21
Step 6: IID Module Test (Power To The Pilot Valve).....	22
Step 7: Pilot Spark Test.....	23
Step 8: Flame Rectification	24
Step 9: IID Module Test.....	25
Step 10: Main Burner Test.....	26
WIRING DIAGRAM - 118/119 SERIES CONTROLS	27

INTRODUCTION

This Service Handbook covers the water heater Model and Series numbers listed on the front cover only. The instructions and illustrations contained in this service handbook will provide you with troubleshooting procedures to verify proper operation and diagnose and repair common service problems.

QUALIFICATIONS

QUALIFIED INSTALLER OR SERVICE AGENCY

Installation and service of this water heater requires ability equivalent to that of a Qualified Agency (as defined by ANSI below) in the field involved. Installation skills such as plumbing, air supply, venting, gas supply and electrical supply are required in addition to electrical testing skills when performing service.

ANSI Z223.1 2006 Sec. 3.3.83: "Qualified Agency" - "Any individual, firm, corporation or company that either in person or through a representative is engaged in and is responsible for (a) the installation, testing or replacement of gas piping or (b) the connection, installation, testing, repair or servicing of appliances and equipment; that is experienced in such work; that is familiar with all precautions required; and that has complied with all the requirements of the authority having jurisdiction."

SERVICE WARNING

If you are not qualified (as defined by ANSI above) and licensed or certified as required by the authority having jurisdiction to perform a given task do not attempt to perform any of the procedures described in this service handbook. If you do not understand the instructions given in this service handbook do not attempt to perform any procedures outlined in this service handbook.

SERVICE REMINDER

When performing any troubleshooting step outlined in this service handbook always consider the wiring and connectors between components. Perform a close visual inspection of all wiring and connectors to and from a given component before replacement. Ensure wires were stripped before being crimped in a wire connector, ensure wires are crimped tightly in their connectors, ensure connection pins in sockets and plugs are not damaged or worn, ensure plugs and sockets are mating properly and providing good contact.

Failure to perform this critical step or failing to perform this step thoroughly often results in needless down time, unnecessary parts replacement, and customer dissatisfaction.

TOOLS RECOMMENDED

- Instruction Manual that came with the water heater.
- All tools common to installation and service of commercial water heaters such as hand tools, screwdrivers, pipe wrenches etc.
- Hex (Allen) wrench sizes: 5/32", 1/8", 1/4" and 5/16"
- Digital manometer: Range -20.00 to +20.00" W.C. Resolution - 0.01" W.C. Required to test supply gas pressure.
- Digital Multi Meter; capable of measuring:
 - AC/DC Voltage.
 - Ohms.
 - DC micro amps (μ A).

INSTALLATION CONSIDERATIONS

This section of the Service Handbook covers some of the critical installation requirements that, when overlooked, often result in operational problems, down time and needless parts replacement. Costs to correct installation errors are not covered under the limited warranty. Ensure all installation requirements and instructions contained in the Instruction Manual that came with the water heater have been followed prior to performing any service procedures.

INSTRUCTION MANUAL

Have a copy of the Instruction Manual that came with the water heater on hand for the model and series number being serviced. Installation information given in this Service Handbook is not a complete installation instruction. Installation information given in this Service Handbook has a limited focus as it applies to servicing the water heater. This Service Handbook does not replace or supersede the Instruction Manual that came with the water heater. Always refer to the Instruction Manual for complete installation instructions. If the Instruction Manual is not on hand, copies can be obtained from the manufacturers web site or by calling the technical support phone number shown on the back cover of this Service Handbook.

CLOSED WATER SYSTEMS

Water supply systems may, because of code requirements or such conditions as high line pressure, among others, have installed devices such as pressure reducing valves, check valves, and back flow preventers. Devices such as these cause the water system to be a closed system.

THERMAL EXPANSION

As water is heated, it expands (thermal expansion). As the volume of water grows there will be a corresponding increase in water pressure due to thermal expansion. Thermal expansion can cause premature tank failure (leakage). This type of failure is not covered under the limited warranty. Thermal expansion can also cause intermittent Temperature-Pressure Relief Valve operation: water discharged from the valve due to excessive pressure build up. This condition is not covered under the limited warranty. The Temperature-Pressure Relief Valve is not intended for the constant relief of thermal expansion. A properly sized thermal expansion tank must be installed on all closed systems to control the harmful effects of thermal expansion. Contact a local plumbing service agency to have a thermal expansion tank installed.

AIR REQUIREMENTS

Carefully review the requirements for combustion and ventilation air in the Instruction Manual that came with the water heater. Failure to meet these requirements when the water heater is installed or overlooking their importance when servicing the water heater often results in needless down time, unnecessary parts replacement, and customer dissatisfaction. An inadequate supply of air for combustion and ventilation can cause recirculation of combustion products resulting in contamination that may be hazardous to life. Such a condition often will result in a yellow, luminous burner flame, causing sooting of the combustion chamber, burners and flue tubes and creates a risk of asphyxiation.

CONTAMINATED AIR

Combustion air that is contaminated can greatly diminish the life span of the water heater and water heater components such as hot surface igniters and burners. Propellants of aerosol sprays, beauty shop supplies, water softener chemicals and chemicals used in dry cleaning processes that are present in the combustion, ventilation or ambient air can cause such damage.

Do not store products of this sort near the water heater. Air which is brought in contact with the water heater should not contain any of these chemicals. If necessary, uncontaminated air should be obtained from remote or outdoor sources.

VENTING

This section of the Service Handbook is not a complete venting installation instruction. Refer to the Instruction Manual that came with the water heater; ensure the venting has been installed per all Instruction Manual requirements. Costs to correct installation errors are not covered under the limited warranty.

The instructions in this section on venting must be followed to avoid choked combustion or recirculation of flue gases. Such conditions cause sooting or risks of fire and asphyxiation.

Heater must be protected from freezing downdrafts. Remove all soot or other obstructions from the chimney that will retard a free draft.


Type B venting is recommended with these heaters. For typical venting application refer to Technical Data Venting in the Instruction Manual. This water heater must be vented in compliance with all local codes, the current revision of the National Fuel Gas Code (ANSI-Z223.1) and with the Category I Venting Tables.

If any part of the vent system is exposed to ambient temperatures below 40°F it must be insulated to prevent condensation.


- Do not connect the heater to a common vent or chimney with solid fuel burning equipment. This practice is prohibited by many local building codes as is the practice of venting gas fired equipment to the duct work of ventilation systems.
- Where a separate vent connection is not available and the vent pipe from the heater must be connected to a common vent with an oil burning furnace, the vent pipe should enter the smaller common vent or chimney at a point above the large vent pipe.

All SBD water heaters are classified by ANSI as category I (non-condensing, negative pressure venting) appliances. They are approved for Type B venting. For larger applications, SBD model water heaters can be common vented together either in a tapered manifold or constant size manifold. (Follow National Fuel Gas Code requirements for sizing and installation.) SBD models may be common vented only with other category I appliances. (See venting section in the National Fuel Gas Code).

POWER VENT KITS FOR SIDEWALL VENTING



SBD model water heaters can be used with power vent kits for sidewall venting. State Water Heaters offers power vent kits for use on installations with a maximum of 100 equivalent feet of vent piping. The power vent kits also use type B vent materials. When power venting, specific exterior clearances must be maintained, as outlined in the National Fuel Gas Code. (NFPA 54, ANSI A223.1, sec 7.8)



GAS SUPPLY SYSTEMS

Low pressure building gas supply systems are defined as those systems that cannot under any circumstances exceed 14" W.C. (1/2 PSI Gauge). These systems do not require pressure regulation. Measurements should be taken to insure that gas pressures are stable and fall within the requirements stated on the water heater rating plate. Readings should be taken with all gas burning equipment off (static pressure) and with all gas burning equipment running at maximum rate (dynamic pressure). The gas supply pressure must be stable within 1.5" W.C. from static to dynamic pressure to provide good performance. Pressure drops that exceed 1.5" W.C. may cause rough starting, noisy combustion or nuisance outages. Increases or spikes in static pressure during off cycles may cause failure to ignite or in severe cases damage to appliance gas valves. If your low pressure system does NOT meet these requirements, the installer is responsible for the corrections.

High Pressure building supply systems use pressures that exceed 14" W.C. (1/2 PSI Gauge). These systems must use field supplied regulators to lower the gas pressure to less than 14" W.C. (1/2 PSI Gauge). Water heaters require gas regulators that are properly sized for the water heater input and deliver the rating plate specified pressures. Gas supply systems where pressure exceeds 5 PSI often require multiple regulators to achieve desired pressures. Systems in excess of 5 PSI building pressure should be designed by gas delivery professionals for best performance. Water heaters connected to gas supply systems that exceed 14" W.C. (1/2 PSI Gauge) at any time must be equipped with a gas supply regulator.

All models require a minimum gas supply pressure of 4.5" W.C. for natural gas and 11.0" W.C. for propane gas. The minimum supply pressure is measured while gas is flowing (dynamic pressure). The supply pressure should never fall below 4.5" W.C. for natural gas and 11.0" W.C. for propane gas. The supply pressure should be measured with all gas fired appliances connected to the common main firing at full capacity. If the supply pressure drops more than 1.5" W.C. as gas begins to flow to the water heater then the supply gas system including the gas line and/or the gas regulator may be restricted or undersized. See Supply Gas Regulator section and Gas Piping section of this manual. The gas valve on all models has a maximum gas supply pressure limit of 14" W.C. The maximum supply pressure is measured while gas is not flowing (static pressure).

SUPPLY GAS REGULATOR

The maximum allowable gas supply pressure for this water heater is 14 inches W.C. (3.48 kPa). Install a positive lock-up gas pressure regulator in the gas supply line if inlet gas pressure can exceed 14 inches W.C. (3.48 kPa) at any time. Regulators must be sized/used according to manufacturer's specifications.

If a positive lock-up regulator is required follow these instructions:

1. Positive lock-up gas pressure regulators must be rated at or above the input Btu/hr rating of the water heater they supply.
2. Positive lock-up gas pressure regulator(s) should be installed no closer than 3 equivalent feet (1 meter) and no farther than 8 equivalent feet (2.4 meters) from water heater's inlet gas connection.
3. After installing the positive lock-up gas pressure regulator(s) an initial nominal supply pressure setting of 7.0" W.C. while the water heater is operating is recommended and will generally provide good water heater operation. Some addition adjustment maybe required later to maintain a steady gas supply pressure.
4. When installing multiple water heaters in the same gas supply system it is recommended that individual positive lock-up gas pressure regulators be installed at each unit.

GAS PIPING

Contact your local gas service company to ensure that adequate gas service is available and to review applicable installation codes for your area.

Size the main gas line in accordance with Table below. The figures shown are for straight lengths of pipe at 0.5 in. W.C. pressure drop, which is considered normal for low pressure systems. Note: Fittings such as elbows, tees and line regulators will add to the pipe pressure drop. Also refer to the latest version of the National Fuel Gas Code.

Schedule 40 Steel or Wrought Iron Pipe is the preferred material for the gas line of this water heater. It is imperative to follow the sizing recommendations in the latest version of the National Fuel Gas Code if Corrugated Stainless Steel Tubing (CSST) is used as the gas line for this water heater.

The heater is not intended for operation at higher than 14.0" W.C.- natural gas, (1/2 pound per square inch gage) supply gas pressure. Exposure to higher supply pressure may cause damage to the gas valve which could result in fire or explosion. If overpressure has occurred such as through improper testing of gas lines or emergency malfunction of the supply system, the gas valve must be checked for safe operation. Make sure that the outside vents on the supply regulators and the safety vent valves are protected against blockage. These are parts of the gas supply system, not the heater. Vent blockage may occur during ice storms.

GAS SUPPLY PIPE LENGTHS (IN FEET)
Maximum Equivalent Pipe Length - Natural Gas Only

Input rate (BTU/HR)	Schedule 40 Steel or Wrought Iron Pipe				
	1/2"	3/4"	1"	1 1/4"	1 1/2"
120,000	20	70	200	200	200
154,000	10	40	150	200	200
180,000	-	30	100	200	200
199,000	-	30	90	200	200
250,000	-	20	60	200	200
275,000	-	10	50	200	200
310,000	-	10	40	150	200
366,000	-	-	30	100	200
390,000	-	-	20	100	200
Fitting Type*	Equivalent length in feet				
45°Ell	0.7	1.0	1.2	1.6	1.9
90°Ell	1.6	2.1	2.6	3.5	4.0
Tee	3.1	4.1	5.2	6.9	8.0
Natural Gas 0.60 Specific Gravity, 0.50" W.C. Pressure Drop					

*Screwed Fittings


It is important to guard against gas valve fouling from contaminants in gas ways. Such fouling may cause improper operation, fire or explosion.

If copper supply lines are used they must be internally tinned and certified for gas service. Before attaching the gas line, be sure that all gas pipe is clean on the inside. The instructions in this section on venting must be followed to avoid choked combustion or recirculation of flue gases. Such conditions cause sooting or risks of fire and asphyxiation.

To trap any dirt or foreign material in the gas supply line, a sediment trap must be incorporated in the piping (see Figure below). The sediment trap must be readily accessible and not subject to freezing conditions. Install in accordance with recommendations of serving gas suppliers. Refer to the latest version of the National Fuel Gas Code.

To prevent damage, care must be taken not to apply too much torque when attaching gas supply pipe to gas valve inlet. Apply joint compounds (pipe dope) sparingly and only to the male threads of pipe joints. Do not apply compounds to the first two threads. Use compounds resistant to the action of liquefied petroleum gases.

Be sure the gas meter has sufficient capacity to supply the full rated gas input of the water heater as well as the requirements of all other gas fired equipment supplied by the meter. If gas meter is too small, ask the gas company to install a larger meter having adequate capacity.



GAS PIPING AND SEDIMENT TRAP INSTALLATION

	WARNING
	Fire and Explosion Hazard <ul style="list-style-type: none">• Use joint compound or Teflon tape compatible with propane gas.• Leak test before placing the water heater in operation.• Disconnect gas piping and main gas shutoff valve before leak testing.• Install sediment trap in accordance with NFPA 54.

Any time work is done on the gas supply system perform a leak test to avoid the possibility of fire or explosion.

1. For test pressures exceeding 1/2 psi (3.45 kPa) disconnect the water heater and its Main Gas Shutoff Valve from the gas supply piping system during testing, see Figure above. The gas supply line must be capped when disconnected from the water heater.
2. For test pressures of 1/2 psi (3.45 kPa) or less, the water heater need not be disconnected, but must be isolated from the supply gas line by closing the Main Gas Shutoff Valve during testing.
3. Coat all supply gas line joints and connections upstream of the water heater with a non-corrosive soap and water solution to test for leaks. Bubbles indicate a gas leak. Do not use matches, candles, flame or other sources of ignition for this purpose.
4. Repair any leaks before placing the water heater in operation.

PURGING

Gas line purging is required with new piping or systems in which air has entered.

Purging should be performed per the current edition of NFPA 54 the National Fuel Gas Code.

FEATURES AND COMPONENTS

THE HYDROCANNON (SELF-CLEANING SYSTEM)

These units include The Hydrocannon (Self-Cleaning System) installed in the front water inlet. The Hydrocannon inlet tube can only be used in the front water inlet connection. Do not install the Hydrocannon inlet tube in either the top or back inlet water connection. The Hydrocannon must be oriented correctly for proper function. There is a marked range on pipe nipple portion of the Hydrocannon, that must be aligned with top of inlet spud. A label above the jacket hole has an arrow that will point to marked portion of pipe nipple if the orientation is correct. If the arrow does not point within the marked range on pipe nipple, adjust the pipe nipple to correct. A pipe union is supplied with the Hydrocannon to reduce probability of misaligning the Hydrocannon accidentally while tightening the connection to inlet water supply line. Improper orientation of the Hydrocannon can cause poor performance of heater and can significantly reduce outlet water temperatures during heavy draws.




THE HYDROCANNON MAY HAVE 1, 3 OR 7 CROSS TUBES

AUTOMATIC FLUE DAMPER

All units are equipped with an automatic flue damper that reduces heat loss during the OFF cycles. The automatic flue damper drive assembly is a field replaceable part and may be obtained by contacting State Water Heaters, 500 Tennessee Waltz Parkway, Ashland City, TN 37015, Parts: (800) 821-2017.

Each automatic flue damper drive assembly is equipped with a “Service Switch”, as shown in Figure below. The “Service Switch” has 2 positions: AUTOMATIC OPERATION and HOLD OPEN DAMPER. For normal operation the switch should be in the AUTOMATIC OPERATION position.

If there is a problem with the damper the “Service Switch” can be placed in the HOLD OPEN DAMPER position. When the switch is placed in the HOLD OPEN DAMPER position the damper disc will rotate to the open position and the heater may be used until vent assembly is repaired or replaced. DO NOT turn the damper disc manually; damage will occur to the drive assembly if operated manually. Refer to TESTING DAMPER OPERATION section of this manual for additional information.




NOTE: DAMPER DISC SHOWN IN OPEN POSITION

FLUE DAMPER


UNCRATING

The heater is shipped with the flue damper already installed. The wiring conduit runs from the thermostat to the damper drive cover. Before turning unit on, check to make sure the wiring conduit is securely plugged into damper drive.

GAS CONTROL VALVE



For Natural Gas



WHITE-RODGERS GAS VALVE

For Propane (LP)

- Inlet screen helps protect from debris.
- Tamper resistant screws.
- Conveniently located ON/OFF switch.
- Inlet and Outlet pressure taps.
- Adjustable gas regulator.

Note: ON/OFF switch must be in the ON position to perform ohm/continuity tests. ON/OFF switch replaced the gas cock on this new valve design.

GAS PRESSURE SPECIFICATIONS:

MODELS	NATURAL SBD 71120-100390	PROPANE SBD 71120-100390
Maximum Gas Supply Pressure	13.8" W.C.	13.8" W.C.
Minimum Gas Supply Pressure	4.5" W.C.	11.0" W.C.
† Pilot Burner Pressure	3.5" W.C.	10.0" W.C.
† Main Burner/ Manifold Pressure	3.5" W.C.	10.0" W.C.

†. Gas pressures given have a tolerance of ± 0.3 " W.C.

WHITE RODGERS INTEGRATED TEMPERATURE CONTROL SWITCH


The digital thermostat contains the high limit (energy cutout) switch. The high limit switch interrupts main burner gas flow should the water temperature reach 203°F (95°C).

In the event of high limit switch operation, the water heater cannot be restarted unless the water temperature is reduced to approximately 120°F (49°C). The high limit reset button on the front of the control then needs to be depressed.

Continued manual resetting of high limit control, preceded by higher than usual water temperature is evidence of high limit switch operation. The following is a possible reason for high limit switch operation:


- A malfunction in the thermostatic controls would allow the gas control valve to remain open causing water temperature to exceed the thermostat setting. The water temperature would continue to rise until high limit switch operation.

Contact your dealer or service agent if continued high limit switch operation occurs.



STATUS LEDS


The Power Status LED is green, ECO, ECO Reset, and Call for Heat Status LEDs are red.



LED STATUS	INDICATION	ACTION TO TAKE
Power On. Call for heat On.	Power is On, a call for heat currently active.	Normal operation.
Power On. ECO On.	ECO has locked out control, tank temperature exceeded 203°F.	Check for excessive temperature/ cool down tank.
Power On. Reset On.	Tank temperature has cooled below 120°F after ECO lock out, can be reset.	Press manual reset, determine cause for ECO lock out.

ELECTRONIC IGNITION CONTROL/ IGNITION MODULE

Each heater is equipped with a Honeywell ignition module. The solid state ignition control ignites the pilot burner gas by creating a spark at the pilot assembly. Pilot gas is ignited and burns during each running cycle. The main burner and pilot gases are cut off during the OFF cycle. Pilot gas ignition is proven by the pilot sensor. Main burner ignition will not occur if the pilot sensor does not first sense pilot ignition.




Continuous Retry for Ignition
90 second trial/ 5 minute off.

Before calling your service agent, the following checklist should be examined to eliminate obvious problems from those requiring replacement or servicing.

- Check that “main manual gas shut-off valve” is fully open and that gas service has not been interrupted.
- Check that after following the water OPERATING INSTRUCTIONS, the “Top Knob” of the gas control valve is in “ON” position.
- Check electrical supply to the water heater for possible blown (or tripped) fusing or power interruption.
- Is the water temperature in tank below the thermostat dial setting on the thermostat (calling for heat)?
- It is possible that the high limit (E.C.O.) has functioned to shut off the water heater. Contact your serviceman if limit continues to function to shut off water heater.

SEQUENCE OF OPERATION FLOW CHART



TROUBLESHOOTING CHECKLIST

COMPLAINT	CAUSE	REMEDY	
		USER	QUALIFIED SERVICE AGENCY
Water not hot enough.	Thermostat set too low.	Set thermostat dial to a higher temperature.	
	Upper and/or lower temperature probe out of calibration.	Call qualified service agency.	Check continuity and resistance (Ohms) of upper and lower thermostat probes. Replace probes if out of specification.
Insufficient hot water	Thermostat set too low.	Set thermostat dial to a higher temperature.	
	Upper and/or lower temperature probe out of calibration.	Call qualified service agency.	Check continuity and resistance (Ohms) of upper and lower thermostat probes. Replace probes if out of specification.
	Main manual gas shutoff valve partially closed.	Open main manual gas shutoff valve to fullest extent.	
	Heater too small for demand.	Space usage to give heater time to restore water temperature.	
	Heater recovery is slower.	Call qualified service agency.	Check gas input. If incorrect, adjust gas pressure or replace main burner orifice.
	Draft hood not installed or one or more baffles.	Call qualified service agency.	Install draft hood or baffles as furnished with unit.
Water temperature too hot.	Thermostat set too high.	Set thermostat to a lower setting.	
Heater makes sounds: sizzling.	Condensation on outside of tank - normal.		
Rumbling.	Sediment accumulation on bottom of tank.	Drain a quantity of water through drain valve. If rumbling persists, call a qualified service agency.	Delime heater.
Ticking or metallic sounds.	Expansion and contraction-normal.		
Pounding / water hammer.	Air chambers in piping have become waterlogged. Thermal expansion tank damaged, improperly charged, or improperly sized.	Drain piping system and refill. Heater must be off while this is being done. Check thermal expansion tank charge pressure when the water system pressure is zero.	Follow the manufacturer's instructions for proper charging of the thermal expansion tank.
Combustion noises.	Too much primary air.	Adjust shutters.	
	Overfired heater. Incorrect burners or orifice for types of gas used.	Call qualified service agency.	Check and correct as necessary.
Water leaks.	Drain valve not closed tightly.	If drain valve cannot be closed tightly, replace.	
	If leakage source cannot be corrected or identified, call qualified service agency.	Shut off gas supply to heater and close cold water inlet valve to heater.	Repair or in case of suspected tank leakage, be certain to confirm before replacing heater.
Gas odors.	Heater is overfired.	Shut off gas supply to heater and call qualified service agency.	Check for sooted flue passage.
			Check for obstructed vent line.
			Check backdraft or lack of draft.
			Draft hood may be improperly installed or not sized properly.
	Possible gas leaks.	Shut off gas supply to heater and call gas company at once.	

GENERAL SERVICE CHART

Condition	Cause	Solution
DAMPER OPENS NO POWER TO IID MODULE	• DAMPER NOT FULLY OPEN	• REPLACE DAMPER.
	• DEFECTIVE PROTECTOR SWITCH	• REPLACE PC BOARD.
PILOT LIGHTS, SPARKS CONTINUOUSLY	PILOT FLAME NOT PROVING	SEE FLAME RECTIFICATION - STEP 8.
HEATER WILL NOT IGNITE	NOT PROVING PILOT FLAME EXISTENCE	INTERRUPT 120 VAC POWER. • CHECK GROUND WIRE ATTACHMENT. • CLEAN OR REPLACE PILOT ASSEMBLY.
	PILOT GAS NOT COMPLETELY INTERRUPTED AT END OF HEATING CYCLE	• CHECK SUPPLY GAS PRESSURE. • REPLACE GAS VALVE.
WEEPING TEMPERATURE AND PRESSURE RELIEF VALVE	• THERMAL EXPANSION	ADD THERMAL EXPANSION TANK.
	• FAULTY VALVE	REPLACE RELIEF VALVE.
LARGE VOLUME WATER RELIEF FROM T&P VALVE	• EXCESSIVE WATER • TEMPERATURE	CHECK WIRING REPLACE DUAL CONTROLLER.
	• FAULTY RELIEF VALVE	REPLACE RELIEF VALVE.
PREMATURE TANK LEAKAGE	CONDENSATION	• INCREASE STORED WATER TEMPERATURE AND CONFIRM PROPERLY SIZED APPLICATION.
	CONTAMINATED AIR	• REMOVE CONTAMINANTS. • SUPPLY CLEAN COMBUSTION AIR.
	WATER HAMMER	• ADD WATER HAMMER ARRESTOR. • REDUCE WATER PRESSURE. • REMOVE UNNECESSARY CHECK VALVES.
	THERMAL EXPANSION	ADD THERMAL EXPANSION TANK.
	DEPLETED ANODES	SCHEDULE ANODE CHECKS - REPLACE AS NEEDED.
DAMPER WILL NOT OPEN	BINDING SHAFT	SUPPORT VENTING
	DAMPER MOTOR	• REPLACE DAMPER.
NO SPARK AT PILOT - DAMPER FULLY OPEN	DAMPER ASSEMBLY	SEE STEP 7. Services Switch may bypass problem until replacement part is received. REPLACE DAMPER .
	IID MODULE	REPLACE IID STEP 6.
	SPARK CABLE	REPLACE CABLE STEP 7.

FAULT AND WARNING CODES


STEP 1. TROUBLESHOOTING THE WATER HEATERS

CHECK/REPAIR:

- Check that 120 VAC is supplied to the heater.
- Make sure the tank is full of water.
- Make sure the gas is supplied to the unit.


EFFIKAL DAMPER

The wiring colors from the damper PC Board are different colors than the wires on the heater wiring harness. The male/female plugs to connect the damper board to the heater harness join in only one way.



The heater harness wires still serve the same function:

- Black – 24V Constant if high limit closed
- Yellow – 24V To damper if the thermostat is closed
- Red – 24V From damper to IID if damper closes end switch
- White – Neutral (common)




HARNESS CHART

Heater Harness	Function	Damper Harness
Black	24V Hot	1 - Brown
Yellow	24V from Thermostat	2 - Orange
Red	24V from Damper	3 - Yellow
White	24V Common	4 - Black

CONDITION:

- Damper closed.
- High Limit closed.




FLUE DAMPER

Do not turn damper open manually or motor damage will result, use the service switch. All readings are taken from harness receptacle. Do not push meter leads into harness receptacle. This opens the pins and will create connection problems. See the following EFFIKAL RVGP-KSF-SERIES FLUE DAMPER TROUBLE SHOOTING GUIDE.

EFFIKAL RVGP-KSF-SERIES FLUE DAMPER TROUBLESHOOTING GUIDE

Do not turn damper open manually or motor damage will result, use the service switch. All readings are taken from harness receptacle. Do not push meter leads into harness receptacle. This opens the pins and will create connection problems.



Effikal Pinouts & wire colors	Function	Adapter wire colors in*
1. Brown	24 VAC HOT	Black
2. Orange	Signal In	Yellow
3. Yellow	Signal Out	Red
4. Black	24 VAC Common	White

NOTE: DAMPER DISC SHOWN IN OPEN POSITION.

24 VAC.	NORMAL SEQUENCE OF OPERATION						
A. FLUE DAMPER OPEN OR OPENING (Unit is calling for heat and damper disc should be in vertical position) VOLTAGE ACROSS:	<div style="border: 1px solid black; padding: 5px;"> <p>⚠ WARNING</p> <p>Do not negate the action of any existing safety or operational controls.</p> </div>						
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; padding: 2px;">4 & 1</td> <td style="padding: 2px;">All Times that High Limit is closed</td> </tr> <tr> <td style="padding: 2px;">4 & 2</td> <td style="padding: 2px;">Calling for Heat Open or Opening</td> </tr> <tr> <td style="padding: 2px;">4 & 3</td> <td style="padding: 2px;">During Combustion Damper Open+</td> </tr> </table>		4 & 1	All Times that High Limit is closed	4 & 2	Calling for Heat Open or Opening	4 & 3	During Combustion Damper Open+
4 & 1		All Times that High Limit is closed					
4 & 2	Calling for Heat Open or Opening						
4 & 3	During Combustion Damper Open+						
B. FLUE DAMPER CLOSED (Unit is not calling for heat and damper disc should be in horizontal position) NOTE: POSITION 4 IS COMMON AND POSITION 3 IS HOT 24 VAC VOLTAGE ACROSS:							
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; padding: 2px;">4 & 1</td> <td style="padding: 2px;">All Times that High Limit is closed</td> </tr> <tr> <td colspan="2" style="padding: 2px;">NO VOLTAGE ACROSS:</td> </tr> <tr> <td style="padding: 2px;">4 & 3 or 4 & 2</td> <td style="padding: 2px;">1. Thermostat not calling for heat.</td> </tr> </table>	4 & 1	All Times that High Limit is closed	NO VOLTAGE ACROSS:		4 & 3 or 4 & 2	1. Thermostat not calling for heat.	
4 & 1	All Times that High Limit is closed						
NO VOLTAGE ACROSS:							
4 & 3 or 4 & 2	1. Thermostat not calling for heat.						

ABNORMAL OPERATION			
A. NOTHING WORKING NO VOLTAGE ACROSS:	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; padding: 2px;">4 & 1</td> <td style="padding: 2px;"> <ol style="list-style-type: none"> 1. High Limit has tripped and is OPEN. Determine reason for tripping of high limit 2. Bad Transformer 3. Loose or broken connections 4. Blown fuse or circuit breaker 5. Disconnect switch off 6. Harness not plugged into water heater receptacle </td> </tr> </table>	4 & 1	<ol style="list-style-type: none"> 1. High Limit has tripped and is OPEN. Determine reason for tripping of high limit 2. Bad Transformer 3. Loose or broken connections 4. Blown fuse or circuit breaker 5. Disconnect switch off 6. Harness not plugged into water heater receptacle
4 & 1	<ol style="list-style-type: none"> 1. High Limit has tripped and is OPEN. Determine reason for tripping of high limit 2. Bad Transformer 3. Loose or broken connections 4. Blown fuse or circuit breaker 5. Disconnect switch off 6. Harness not plugged into water heater receptacle 		
B. DAMPER HAS OPENED, NO COMBUSTION VOLTAGE ACROSS:	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; padding: 2px;">4 & 1; 4 & 2; 4 & 3:</td> <td style="padding: 2px;"> <ol style="list-style-type: none"> 1. Check for power at ignition module terminals. If 24 VAC power is present damper is working properly. 2. Defective component in water heater after the flue damper. 3. If 24 VAC is not present at the ignition module, look for loose or broken connections between damper and ignition module. 4. If the connections from damper to ignition module seem proper, replace damper assembly. If a damper assembly is not available, place the service switch in the hold open position. This should keep the damper in the open position and allow the customer to have automatic heat, until a replacement damper can be installed. </td> </tr> </table>	4 & 1; 4 & 2; 4 & 3:	<ol style="list-style-type: none"> 1. Check for power at ignition module terminals. If 24 VAC power is present damper is working properly. 2. Defective component in water heater after the flue damper. 3. If 24 VAC is not present at the ignition module, look for loose or broken connections between damper and ignition module. 4. If the connections from damper to ignition module seem proper, replace damper assembly. If a damper assembly is not available, place the service switch in the hold open position. This should keep the damper in the open position and allow the customer to have automatic heat, until a replacement damper can be installed.
4 & 1; 4 & 2; 4 & 3:	<ol style="list-style-type: none"> 1. Check for power at ignition module terminals. If 24 VAC power is present damper is working properly. 2. Defective component in water heater after the flue damper. 3. If 24 VAC is not present at the ignition module, look for loose or broken connections between damper and ignition module. 4. If the connections from damper to ignition module seem proper, replace damper assembly. If a damper assembly is not available, place the service switch in the hold open position. This should keep the damper in the open position and allow the customer to have automatic heat, until a replacement damper can be installed. 		
C. DAMPER ROTATES CONTINUOUSLY	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; padding: 2px;"></td> <td style="padding: 2px;">Change the entire damper assembly</td> </tr> </table>		Change the entire damper assembly
	Change the entire damper assembly		
D. DAMPER STICKS	<ol style="list-style-type: none"> 1. Make sure no screws obstruct the damper blade. 2. Make sure damper pipe assembly is not egg shaped. 3. Make sure damper rod is not rubbing on pipe assembly. <p style="margin: 0;">See figure on front page of this insert sheet</p>		

IMPORTANT: DAMPER MUST BE OPEN BEFORE COMBUSTION TAKES PLACE. If all steps have been tried and damper problems persists, contact State Water Heaters (800) 365-8170.

STEP 2: TEST FOR 24VAC BETWEEN BLACK AND ORANGE ON DAMPER PC BOARD

IF	THEN
24VAC is present - damper NOT opening	<ul style="list-style-type: none">• Check Service Switch Position. Replace Damper Assembly.
24VAC is not present.	<ul style="list-style-type: none">• Check Wiring Harness to Thermostat.
24VAC present - Damper Opens	<ul style="list-style-type: none">• Continue to Step 3.

CONDITION:


- Damper rotates continuously.

STEP 3: TEST THE THREE AMP FUSE


CONDITION:

- Test via the terminals on the head of the fuse or by removing the fuse and testing across the blades.
- Verify that there is 120 VAC to the thermostat. Once verified set the meter to check for continuity and perform the checks shown in figure below and on next page.





Visually inspect the fuse to see if it is blown, the inside of the fuse can appear dark, discolored and burnt. The link also will be broken inside.



SYMPTOMS FOR A BLOWN FUSE

- Power, Call for heat, Reset Status and ECO Status lights are not visible on the thermostat.
- 24VAC out of the thermostat via the Yellow wire to ground is not present.
- No Pilot or Main burner flame present.
- Error indication LED light on the Honeywell module not present.

SYMPTOMS FOR A WORKING FUSE

- LED status lights on the thermostat are visible.
- 24 VAC is present out of the thermostat via the Yellow wire to ground.
- 24VAC is present on the Red wire via the 24V terminal found on the Honeywell Module.
- Pilot and or Main burner flame is present.

STEP 4: TEST FOR 24VAC BETWEEN BLACK AND YELLOW ON DAMPER PC BOARD

IF	THEN
24VAC is present	<ul style="list-style-type: none"> • This is correct - Continue to Step 5.
24VAC is not present.	<ul style="list-style-type: none"> • Check Service Switch position. • Check the harness plug connections. • Check that cam on shaft rotates with shaft. • Replace the damper assembly.

STEP 5: WIRE HARNESS TEST

CONDITION:

- Damper Open, no 24VAC to module "24VAC" terminal.



Test for 24 VAC between terminal 24V on the IID module, and 24V GND.

IF	THEN
24VAC is present	<ul style="list-style-type: none"> • This is correct - Continue to Step 5.
24VAC is not present.	<ul style="list-style-type: none"> • Check Service Switch position. • Check the harness plug connections. • Check that cam on shaft rotates with shaft. • Replace the damper assembly.

Note: This test may be easier to conduct by removing the red wire from the IID terminal. Test for 24 VAC between the red wire and ground. Reconnect the red wire to the 24V terminal after the test.

STEP 6: IID MODULE TEST (POWER TO THE PILOT VALVE)

CONDITION:

- 24VAC to module, no pilot.




Using a multimeter, test for 24 VAC between terminal PV and 24 V (GND) on the IID during the 90 second trial for ignition.

IF	THEN
The meter does not read 24 VAC and the IID module is not between ignition trials:	<ul style="list-style-type: none"> • Replace the module.
The meter does read 24 VAC:	<ul style="list-style-type: none"> • Go to Step 7.

STEP 7: PILOT SPARK TEST

CONDITION:

- 24VAC at PV, no pilot.




Visually/audibly check for spark at the pilot assembly.

Note: The pilot burner mounts on the left side of the main burner.

IF	THEN
The igniter is not sparking during the 90 second trial for ignition.	Check for: <ul style="list-style-type: none"> • A 7/64" spark gap. • Spark cable continuity. • Ground cable continuity. • Replace module.
Sparking is present.	<ul style="list-style-type: none"> • Check the gas valve.


Power To Module May Be Interrupted To Reset.



STEP 8: FLAME RECTIFICATION

CONDITION:

- Pilot Flame Noted, Pilot Sparking Continues, No Main Burner.



Note: Flame rectification means that an alternating current (AC) signal is changed to a direct current (DC) signal. The pilot flame is the 'switch' which connects the pilot hood to the igniter and ground. If the pilot hood and igniter sensor had the same surface area, the flame 'switch' would conduct an AC signal. Because the pilot surface is greater than the igniter surface, the signal becomes a DC current that the module can interpret. The pilot hood must be properly grounded and the pilot flame must remain in contact with both surfaces for the flame proving signal to remain constant. If the signal is broken for just 8 tenths of a second, the heater will cycle off. **Sparking at the pilot will continue if an insufficient signal is received by the module. The pilot burner mounts on the left side of the main burner.**

Sparking at the pilot will stop almost immediately after the ignition module senses the pilot flame.

IF	THEN
Sparking continues after pilot is established:	<ul style="list-style-type: none">• Check wire connections.• Check flame contact between hood and lighter.• Clean pilot burner surfaces.• Replace pilot assembly.
Sparking stops:	<ul style="list-style-type: none">• Go to Step 9.

STEP 9: IID MODULE TEST

CONDITION:

- Pilot Flame Noted, No Sparking, No Main Burner.




Using a multimeter, test for 24 VAC between terminal MV on the IID and 24V (GND).

IF	THEN
24 VAC is not present:	<ul style="list-style-type: none"> • Replace the IID module. Check the gas valve before applying power to replacement module.
24 VAC is present:	<ul style="list-style-type: none"> • Check the gas valve.

STEP 10: MAIN BURNER TEST

CONDITION:


- Pilot flame Noted, Main burner Check.



Visually check for main burner.

IF	THEN
The main burner ignites:	<ul style="list-style-type: none">• Sequence is complete.
The main burner does not ignite.	<ul style="list-style-type: none">• Check gas supply.• Check gas control valve operation before replacing.

WIRING DIAGRAM - 118/119 SERIES CONTROLS



IF ANY OF THE ORIGINAL WIRE AS SUPPLIED MUST BE REPLACED, USE ONLY TYPE 105° C THERMOPLASTIC OR EQUIVALENT. FLAME SENSOR IGNITION CABLE MUST BE 250° C TYPE F.

NOTES

NOTES

COMMERCIAL GAS WATER HEATERS

For additional information contact:

State Water Heaters

500 Tennessee Waltz Parkway, Ashland City, TN 37015

Technical Support: 800-365-8170 • Parts: 800-821-2017

www.statewaterheaters.com